



5



No	Name	Code	No	Name	Code
1	UM.HD.BOLT	613071	37	PLATE MOUNT	577416
2	FRONT BRACKET	574394	38	PUSHER	613526
3	EXHAUST COVER	577407	39	SPRING	613060
4	EXHAUST FILTER	613004	40	PUSHER STOPPER	613527
5	CAP ASM.	577406	41	ROLLED PIN	613138
6	HEX.SOC.HD.BOLT	617376	42	ROLLED PIN	613528
7	CAP	577408	43	PUSHER GUIDE	577417
8	SPRING	613102	44	SPIRAL SPRING ASM.	613135
9	O-RING	613103	45	NAIL GUIDE LINER	613535
10	PISTON HEAD VALVE	613104	46	MAGAZINE	577423
11	O-RING	613105	47	NAIL STOPPER	613533
12	SEAL	613106	49	MAGAZINE COVER	613532
13	PLAIN WASHER	613107	51	LOCK NUT	613147
14	PISTON STOPPER	613108	52	BRACKET	613534
15	O-RING	613110	53	FLAT WASHER	613149
17	DRIVER ASSEMBLY	613515	55	COVER	613400
18	CYLINDER	577409	56	O-RING	613029
19	O-RING	613113	57	RUBBER GRIP	576538
20	CYLINDER RING	613114	58	ROLLED PIN	613031
21	COLLAR	577410	59	SPRING	613053
22	O-RING	577411	60	HEX.SOC.HD.BOLT	577418
23	GASKET	613117	61	MAGAZINE ASM.	577422
24	BODY	577412	62	RUBBER PAD	613531
25	LOCK NUT	574426	65	TRIP GUIDE	613055
26	UP BUMPER	613119	69	MODEL LABEL	577424
27	BOTTOM BUMPER	613120	70	LOGO LABEL	577425
28	O-RING	613121	71	AIR NIPPLE	613617
29	NOSE	577414	72	CONTACT TRIGGER KIT	577428
30	HEX.SOC.HD.BOLT	613525	74	CONTACT LABEL	577185
31	SPRING	613128	80	SET PLATE	613518
32	UPPER SAFETY LEVER	577420	82	SWITCH ASM.	613124
33	SAFETY LEVER	613522	85	UM.HD.BOLT	577415
34	HEX.SOC.HD.BOLT	577421	86	SEQUENTIAL TRIGGER ASM.	613123
36	PUSHER ASM.	613530	97	SPACER	577419